

WAKOL D 3201 VliesFix

Technical Information

Area of application

Fixation for the laying of

- dimensionally stable textile floorings with fleece backing on absorbent and non-absorbent subfloors indoors.

Fixed coverings can be removed again without damage on the subfloors.

Special properties



1)



2)



3)

- solvent-free according to TRGS 610
- suitable for wheelchairs
- suitable for underfloor heating
-

1) based on the criteria of GEV (Association for Emission-controlled Laying Materials), classified as EMICODE EC1 : very low in emissions

2) Emissions-certified construction product i.a.w. DIBt principles: Wakol GmbH, 66954 Pirmasens, Z-155.20-102 Dispersion Adhesive

3) Emissions class according to French law

Technical data

Raw material basis:	acrylate dispersion
Airing time:	approx. 10 - 15 minutes, on absorbent subfloors approx. 20 - 30 minutes on non-absorbent subfloors
Open time:	approx. 30 minutes
Cleaning agent:	water, before fixation dries
Storage time:	12 months at room temperature
Storage temperature:	not below + 5°C; sensitive to frost
GISCODE:	D1
EMICODE according to GEV:	EC1

Application and consumption⁴⁾:

Velour roller 120 g/m² tufted floorings with fleece backing

4) Consumption is dependent on surface structure and absorbability of subfloor

Subfloors

The subfloor and the climatic conditions of the room must meet the requirements of DIN 18 365. Subfloors must be level, permanently dry, solid and free from cracks, dirt and adhesion-inhibiting substances.

The fixation of flooring requires smooth surfaces; therefore thoroughly prime subfloors with a rough surface and apply levelling compound. The technical information on the primers and levelling compounds must be heeded.

Existing floors must be completely and firmly attached to the subfloor and have a surface free of wax and care products.

Usage

Stir fixation well before using. Using a velour roller to apply uniformly on the subfloor, avoiding fixation pools. Lay down flooring following airing time and press well. Rub again after a short period. Do not lay down covering too soon, otherwise fixation will be absorbed by the absorbent fleece backing.

Taking up flooring again

To take up the flooring, carefully detach the covering along the edges and slowly pull off. Avoid abruptly tearing up the flooring. When taking up carpets with foam backing, residues of the foam will remain on the subfloor. Soak the remaining Fixation and if foam residues remain on the subfloor with sufficiently warm dish washing fluid. After an acting time of approx. 30 - 60 minutes scrape off the remaining Fixation and the foam residues. Wash again with dish washing fluid.

Warning: fixation residue can remain in the pores of porous subfloors. Priming with WAKOL D 3035 Dispersion Primer or WAKOL D 3040 Primer Concentrate, water diluted 1:2, will improve the removability from porous subfloors.

Important

Do not use at temperatures below +15°C. In cold weather, warm up WAKOL D 3201 VliesFix in due time in heated room. All information is based on approx. 20°C and 65% relative air humidity.

We guarantee the uniform high quality of our products. All data is based on tests and many years of practical experience and refers to standardised conditions. The variety of materials used and the different construction site conditions, which lie beyond our control, preclude any claims based on this data. We therefore recommend making sufficient trials. Accompanying flooring manufacturer's instructions and the currently applicable codes must be observed. We gladly provide technical advice.

The product data sheets can be found in their latest version at www.wakol.com.

This Technical Information of 07.10.2013 supersedes all previous versions.