

WAKOL D 3270 SpaltTex

Technical Information

Area of application

Dispersion-based adhesive according to DIN EN 14259 with integrated zip fastener for the laying of

- textile floorings with fleece, synthetic double or latex foam backing
- Fabromont Kugelgarn®

on absorbent subfloors indoors.

By a later removal of the flooring, the adhesive separates himself zipper-like if low level of strength is performed. Floorings can be removed easily and without any remains.

Special properties



1)



2)



3)



4)

- suitable for chairs with castors
- with „zipper-effect“
- suitable over underfloor heating
- Solvent-free according to the definition of TRGS 610

1) Based on the criteria of GEV (Association for Emission-controlled Laying Materials), classified as EMICODE EC1 PLUS: very low in emissions

2) Permitted as marine equipment product by the See-Berufsgenossenschaft Hamburg, Module B and Module D. Declaration of conformity, see www.wakol.de.

3) Emissions class according to French law

4) Emissions-certified construction product i.a.w. DIBt principles: Wakol GmbH, 66954 Pirmasens

Technical data

Raw material base:	Acrylate dispersion
Airing time:	approx. 5 - 10 minutes, depending on trowel notch size, subfloor and covering
Open time:	approx. 15 minutes
Cleaning agent:	Water, before adhesive is drying
Storage temperature:	not below +5 °C, sensitive to frost
Storage time:	approx. 12 months at room temperature
GISCODE:	D1
EMICODE:	EC1 PLUS

Application and consumption⁵⁾:

TKB B1	250 - 300 g/m ²	Textile floorings with fleece, synthetic double or latex foam backing
TKB B2	350 - 400 g/m ²	Textile floorings with coarse textured backing, Fabromont Kugelgarn®

5) Consumption is dependent on surface structure and absorbability of subfloor

Subfloors

The subfloor and the climatic conditions of the room must meet the requirements of DIN 18365. Subfloors must be absorbent, level, permanently dry, firm and free of cracks, dust, dirt and adhesion-inhibiting substances.

Apply corresponding Wakol levelling compounds to non-absorbent and uneven subfloors. The technical information on the primers and levelling compounds must be heeded.

Usage

Stir adhesive well before using. Using a notched trowel, apply uniformly on the subfloor, avoiding adhesive pools. Lay down covering following appropriate airing time and press well. Rub again after a short period.

If necessary, weigh down stubborn edges of covering until adhesive hardens.

For renovation just remove the flooring - the adhesive separates as a zipper. Treat rests of adhesives before the new laying as usually.

Important

Do not use below +15 °C. Warm up the floor covering and adhesive in time in cold weather.

For ship construction the usage is limited to a maximum amount of 400 g/m².

We guarantee the uniform high quality of our products. All data is based on tests and many years of practical experience and refers to standardised conditions. The variety of materials used and the different construction site conditions, which lie beyond our control, preclude any claims based on this data. We therefore recommend making sufficient trials. Accompanying flooring manufacturer's instructions and the currently applicable codes must be observed. We gladly provide technical advice.

The product data sheets can be found in their latest version at www.wakol.com.

This Technical Information of 20.04.2015 supersedes all previous versions.